


DFE-HH Catalogue

Overhead Line Remote Fault Indicator

For Reliable, Secure and Economical Energy System Operation



1. General Description






2. Features

3. Specifications


Subject	Value

4. Dimensions



5. Accessories

**Please refer to User's Manual to get the way the installation.*



indicator parameters, do some configuration or reset indicator on site.

**Please refer to FPI-HAND User's Manual.*



**Easy for maintenance crew to check fault*

6. Order Info

Item	Content

