


# **DFE-HH Catalogue**

**Overhead Line Remote Fault Indicator**

**For Reliable, Secure and Economical Energy System Operation**



# 1. General Description






## 2. Features


## 3. Specifications

Subject	Value


## 4. Dimensions





# 5. Accessories

*\*Please refer to User's Manual to get the way the installation.*



*indicator parameters, do some configuration or reset indicator on site.*

*\*Please refer to FPI-HAND User's Manual.*



*\*Easy for maintenance crew to check fault*

# 6. Order Info

Item	Content

